



iPhone 4 Pentalobe Screws Replacement

5-point Pentalobe screws replacement.

Written By: Walter Galan



INTRODUCTION

Apple has substituted the two bottom Phillips screws near the dock connector with 5-point "Pentalobular" screws.

This guide will illustrate how to replace the Pentalobe screws with good ol' regular Phillips screws.



PARTS:

- [iPhone 4 Liberation Kit](#) (1)
 - [iPhone 4 4S Bottom Screws](#) (1)
-

Step 1 — Pentalobe Screws



- ❗ Before we proceed, let's make sure you have the correct tools for the job.
- iFixit's [iPhone 4/4S Liberation Kit](#) includes:
 - One 5-Point Pentalobe screwdriver
 - One #000 Phillips screwdriver
 - Two 3.6 mm "Liberation" Phillips screws
- Are you ready to break the shackles of hardware oppression and liberate your iPhone? Let's rock!

Step 2



- Use the Pentalobe screwdriver to remove the two 3.6 mm Pentalobe screws near the dock connector.
- ⚠ The 5-Point Pentalobe screwdriver should only be used a limited number of times because it has the potential to strip the screws.

Step 3



- Peel and remove the two 3.6 mm Phillips screws from the iPhone Liberation Card.
- ⓘ Both the Phillips and Pentalobe screws are really small. How small? See for yourself (highlighted in the second picture).

Step 4



- Insert the two 3.6 mm Phillips screws into the screw holes using the provided #000 Phillips screwdriver.
- ★ Huzzah! Your iPhone is now liberated from those pesky "Pentalobular" screws.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-16 06:20:49 PM.